


Accessories for Linear Transducers


- Ball Coupling
- Roller Head
- Ball and Socket Coupling



Z-301

Ball coupling avoids side loads. For use with transducers series LWH, TLH and TEX.
Mounting via internal thread at rod.

Typ	A/D	L	B	C	E	P/N
Z-301-M6/M6		13	36	18	SW12	058001
Z-301_M6/M4		9	37	15	SW10	005679
Z-301-M5/M5		14	36	15	SW12	058002



Z-R50

Roller head to be used with transducers series LS1, TR/TRS and FTI.
Hardened steel roll.
Mounting via external thread M2.5, lock with knurled screw.

Typ	P/N
Z-R50	005678

